

**Suitable for use with TCL / Baylis / Ventus Magic Torch models: 7010/7011, 7016/7017, 7018/7019, 7030/32/33/34/35, VIP7316 & Eco Media Player, EP-MX71 and r e v o l u t i o n, iTravel mp3 Radio**

### MTA01 - MOTOROLA - Square Type

A630, A830, A835, A920, A925, A1000, C331 and C332 (TDMA versions), C333 (CDMA with antenna), C341, C343, C353 (TDMA), C975, E310, E550, E1000, MPx220, ROKR, T280i, T300p, T720, T720i, T721, T721i, T722i, T730, T731, V70, V260, V262, V265, V300, V400, V500, V505, V525, V545, V547, V550, V551, V600, V620, V635, V710, V810, V975, V1050, V60, V60i, V60c, V60p(PTT), V60s, V60t, V60t Color, V60g, V60x, V66, V66i, V120c, 120t, 120x, 120c, 120e, 270c, 280, V200 Personal Communicator



### MTA02 - MOTOROLA - (Mini USB Type)

A780, E770v, E1070, L6, PEBL, RAZR V3, RAZR V3i, RAZR V3x, SLVR, V360, V360v

BLACKBERRY: 6210, 6220, 6230, 6280, 6510, 7100g, 7100i, 7100r, 7100t, 7100v, 7100x, 7105t, 7130e, 7210, 7230, 7250, 7270, 7280, 7290, 7510, 7520, 8700c

**iRiver MP3 Players:** T10 series, T30 series, PMP-100 series, PMC-100 series, H300 Series, H140, H120, H100, iGP-100, iFP-1000 series, iFP-900 series, iFP-800 series, iFP-700 series, iFP-300 series, N10

**GARMIN GPS:** Forerunner 205, Forerunner 203, Forerunner 301, Edge 205, Edge 305

**VODAFONE:** Touch, 541



### MTA03 - NOKIA 3.5mm (This is the charging cable end as supplied with TCL/Baylis/Ventus product)

E60, E70, 1100, 1101, 1110, 1221, 1260, 1261, 1600 2260, 2270, 2285, 2300, 2600, 2650, 2652, 3100, 3105, 3108, 3120, 3200, 3220, 3230, 3285, 3300, 3350, 3360, 3361, 3390, 3395, 3510, 3510i, 3520, 3530, 3560, 3570, 3585, 3585i, 3586, 3586i, 3588i, 3589i, 3590, 3595, 3600, 3620, 3650, 3660, 5100, 5140, 5140i, 5210, 5510, 6020, 6021, 6030, 6060, 6100, 6108, 6170, 6200, 6220, 6225, 6230, 6230i, 6260, 6310, 6310i, 6340, 6340i, 6360, 6370, 6385, 6510, 6560, 6585, 6590, 6590i, 6600, 6610, 6610i, 6620, 6630, 6650, 6670, 6680, 6681, 6800, 6810, 6820, 6822, 7200, 7210, 7250, 7250i, 7260, 7270, 7280, 7380, 7600, 7650, 7700, 7710, 7600, 7610, 7650, 8260, 8265, 8265i, 8270, 8290, 8310, 8390, 8800, 8910, 8910i phones, 9210i, 9290, 9300, 9300i, 9500 Communicators, N-Gage, N-Gage QD

### MTA04 - NOKIA 2mm

1650, 1680, 2600, 2630, 2680, 2760, 3109, 3110, 3250, 3500, 3610, 5000, 5070, 5200, 5220, 5300, 5310, 5500, 5610, 5700, 6070, 6080, 6085, 6086, 6101, 6103, 6111, 6120, 6125, 6121, 6131, 6136, 6151, 6233, 6234, 6270, 6280, 6290, 6300, 6301, 6500, 6555, 7070, 7210, 7310, 7360, 7370, 7373, 7500, 7510, 7610, 8800, C5, E50, E51, E61, E61i, E65, E90, N70, N71, N72, N73, N76, N77, N80, N90, N91, N92, N800, N90, N91, N92, N93, N93i, 770,

**MOTOROLA:** C115, C116, V220



### MTA05 - SAGEM

MY-X series, 3000 series (except 3078, 3088, WA3050), 900 series, V55 / 65 / 66 / 75 / 76



**To obtain your free mobile phone adapter, simply send us a Stamped Self Addressed envelope (90p stamps), together with a note of your Adapter Code from this list. (Please use a small PADDED envelope).**

**IF YOUR PHONE IS NOT SHOWN IN THIS LIST - SORRY, BUT IT IS NOT CURRENTLY SUPPORTED**

## MTA06 - SAMSUNG

A210, A310, A399, A475, A505, A509, A539, A563, A564, A591, -A592, A595, A599, A610, A809, N181, N181, N182, N191, N195, N288, N370, N375, X199, X209, X309, X319, X359, A200, A288, A300, A308, A400, A408, A500, A561, A608, A800, C100, D100, D500, D600, E100, E330, E350, E400, E600, E700, E710, E760, E770, E800, K528, N200, N400, N500, N620, N628, P400, P408, SGH\_P510, Q100, Q200, Q208, Q300, R200, R208, R210, R210S, SGH R220, R225, R225M, S100, S200, S208, S300, S300M, S307, S308, SGH S500, T100, T108, T200, T208, T410, T400, T408, T500, V100, V200, V205, V206, X100, X450, X460, X480, X600, X640, SPH-T100

LG: 5400, 7100



## MTA07 - SAMSUNG

E620, E720, E810, E818, i300, i300X, P730, Z140, Z140V, Z300, Z500, ZV10, ZV30



## MTA08 - SENDO

Most models



## MTA09 - SIEMENS

A35, A36, A40, A50, C25, C28, C35, C35i, C45, M35, M35i, M45, M50, ME45, MT50, S25, S35, S35i, S45, S45i, SL42, SL45, SL45i



## MTA10 - SIEMENS

A51, A52, A53, A55, A57, A60, A62, A65, A70, A75, AL21, AL72, AL75, AL76, AX21, AX72, AX75, AX76, C55, C60, C62, C65, C70, C72, C75, CC55, CC60, CC62, CC65, CC70, CC72, CC75, CF62, CF75, CF110, CFX65, CL75, CX65, CX70, CX75, M55, M60, M65, M75, MC55, MC60, MC65, MC75, ME75, S55, S65, S75, SP55, SP65, SP75, SF65, SK65, SL55, SL65, SL75, SG75, SXG75, SX1



## MTA11 - SONY ERICSSON T-Series

A2218z, A2618, A2618s, A2628, A3618s, F500i, J210i, J300i, K300i, K500i, K508i, K600i, K608i, K700i, P800, P900, P910i, R300d, R300LX, R300z, R320, R320s, R380 WORLD, R380e, R380s, R520m, R600, S700i, T20e, T20s, T28 WORLD, T28z, T29, T29s, T39m, T60c, T60d, T61c, T61d, T61LX, T61z, T62u, T65, T66, T68, T68i, T100, T105, T200, T226, T230, T290i, T300, T306, T310, T316, T600, T610, T616, T620, T630, V600i, V800, Z200, Z300i, Z600, Z800i, Z1010



**To obtain your free mobile phone adapter, simply send us a Stamped Self Addressed envelope (90p stamps), together with a note of your Adapter Code from this list. (Please use a small PADDED envelope).**

**IF YOUR PHONE IS NOT SHOWN IN THIS LIST - SORRY, BUT IT IS NOT CURRENTLY SUPPORTED**



## MTA12 - SONY ERICSSON Fastport System

D750i, J100a, J100c, J100i, J220a, J220c, J220i, J230c, J230i, K310a, K310c, K310i, K320i, K510a, K510c, K510i, K610i, K610im, K750c, K750i, K758c, K790a, K790c, K790i, K800i, M600i, M608c, P990i, V630i, W300c, W300i, W550c, W550i, W600c, W600i, W700c, W700i, W710c, W710i, W800i, W810c, W810i, W830i, W850i, W900c, W900i, W950i, W958c, Z520a, Z520c, Z520i, Z525a, Z525i, Z530c, Z530i, Z550a, Z550c, Z550i, Z558c, Z558i, Z610i, Z710c, Z710i, J220i, K618i, M600i, W800c, W830c



## MTA13 - SAMSUNG - New Style

Samsung (467-S1-SAM) SPH-M610, SCH-U420, SGH-D807, SGH-D900, SGH-I607, SGH-T519, SGH-T509, SGH-T809, SGH-T629, SGH-D520, SGH-D800, SGH-D830, SGH-D807, SGH-E250, SGH-E550, SGH-780, SGH-E870, SGH-E900, SGH-J600, SGH-P300, SGH-T509, SGH-T809, SGH-V804, SGH-X820, SGH-X830, SGH-Z150, SGH-Z400, SGH-Z510, SGH-Z540, C3050



## MTA14 - Micro-USB (New world standard)

**Motorola:** CLIQ, CLIQ MB200, Morrison, DEXT MB, i465 Clutch, A455 Rush 2 / Rival, i776, QA1 Karma, IDEN Series i9 Stature, Q Series Q Global, Q9, Q9h, QA Series Evoke QA4, Hint QA30, RAZR, RAZR-2, VE20, RAZR2 V8, V9, V9m, ROKR E8, U9, V Series Adventure V750, Rapture VU30, Renegade V950 W Series W233, Z Series Krave ZN4, Z9, Zine ZN5,

**Blackberry:** Curve 8530 Aries, 8520, 8900, Bold 9700 / Onyx, Pearl Flip 8220, 8230, Tour 9630 Niagara,

**HTC:** Google Nexus One, Leo / Firestone / HD2

**Kyocera:** E1100 Neo, E2000 Tempo, S1300 Melo, S4000 Mako

**LG:** AX300, AX830 Glimmer, LX400, UX300, UX830 / Glimmer / Vantage, VX8610 Decoy, VX9100 enV2, BL40 New Chocolate, GM750, GT500 Puccini, GT505, GW520, Shine II GD710, Chocolate Touch VX8575 / AX8575, LX370 / AX370 / UX370, MT375 Lyric, AX840 / UX840 Tritan, KF750 / CF750 Secret, VX7100 Glance, AX155, AX265 / UX265 Banter, AX500 Swift, AX585 Rhythm, AX9100, CF360, CT810 Incite, GR500 Xenon, LG830 Spyder, LX265 Rumor2, LX600 Lotus, UX280 Wine, UX585 Rhythm, UX9100, VX11000 EnV Touch, VX5500, VX8360, VX8560 Chocolate 3, VX9200 enV3, VX9600 Versa, VX9700 Dare

**Nokia:** N96, 6500 classic, 7900 Prism, 8600 Luna, 8800 Arte, 8800 Sapphire Arte, N900, N97 mini, 7705 Twist, 6350 Snapper, 6750 Grouper / Mural, 1006, 1606, 2605 Mirage, 6205, 8800 Carbon Arte, N85, N97

**Palm:** Pixi Plus, Pre Plus, Pixi CDMA / Eos CDMA, Pixi GSM / Castle / Eos GSM

Treo 800W, PRO 850

**Samsung:** SCH-i920 / Omnia II CDMA, Instinct, Instinct S50, Instinct HD, SPH-M850, GT S8000 Jet / Cubic, SCH-R850 Caliber, SGH-T939 / Behold 2, SGH-A797 Flight, SGH-A897 Mythic, SPH-i350 / ACE II / Intrepid, SPH-M900 / Instinct Q / Moment, SCH-R350 / SCH-R351 / Freeform, GT-i8000 Omnia II, i7500 / GT-i7500 / Galaxy, M8910 / GT-M8910 / Pixon 12, S5600 / GT-S5600 / Preston Gallery, i8910 HD / Acme / Omnia HD, SCH-R460 Myshot 2, SCH-R560 Messenger 2, SPH-M550 Exclaim, SPH-M560 Reclaim, SCH-R470 TwoStep, SPH-M220, SPH-M320, SPH-M540 Rant, SPH-M630 Highnote, Tocco.

**Sanyo:** S1, Incognito SCP-6760, SCP-2700, SCP-3810, Katana Eclipse, Katana Eclipse X, Katana LX SCP-3800, Pro-200, Pro-700.



To obtain your free mobile phone adapter, simply send us a Stamped Self Addressed envelope (90p stamps), together with a note of your Adapter Code from this list.  
(Please use a small PADDED envelope).

IF YOUR PHONE IS NOT SHOWN IN THIS LIST - SORRY, BUT IT IS NOT CURRENTLY SUPPORTED

## MTA15 - SAMSUNG (Another New Style)

B100, B210, B2100 Xplorer, B2700, B300, B510, B7320 OmniaPRO, B7330 OmniaPRO, C5212, C6625, D807, D880 DuoS, D980 DuoS, E1360, E215, F110 MiCoach, F200, F210, F250, F330, F400, F480 Tocco, F490, F700, G600, G800, i200, i400, i450, i550, i7110, I7500 Galaxy, i780, i900 Omnia, J700, L170, L760, L770, L810 Steel, M110 Solid, M150, M200, M310, M3200 Beat S, M3510 Beat b, M8800 Pixon, P260, P520 Armani, R200, R500, R610, S3030 Tobi, S3500, S3600, S5230 Star, S7330, T409, T439, T539 Beat, T639, T729 Blast, T819, U800 Soul B, Samsung U900 Soul, Z710 Sleek, Z720



## MTA16 - LG ( New Style)

AX8600, CB630 Invision, CP150, CE110, CG180, CU515, CU575 Trax, CU720 Shine, CU915, CU920, KC550, KC780, KC910 Renoir, KE800 Chocolate Platinum, KE850 Prada, KE970 Shine, KF300, KF600 Venus, KF750 Secret, KF900 Prada II, KG320, KG800 Chocolate, KG808, KG810, KG90, KP100, KP500, KU990 Viewty, KS360, MG800C, U830, U970 Shine, VX8700, VX8500 Chocolate,



## MTA17 - Apple

iPhone, (Series 3, 3G, 4, 4S)

**NOTE:** Some Magic Torch models built prior to September 2013 may not be compatible with iPhone charging voltage and will not provide satisfactory charging performance. All Magic Torch models built after September 2013 will be compatible.



**To obtain your free mobile phone adapter, simply send us a Stamped Self Addressed envelope (90p stamps), together with a note of your Adapter Code from this list. (Please use a small PADDED envelope).**

**IF YOUR PHONE IS NOT SHOWN IN THIS LIST - SORRY, BUT IT IS NOT CURRENTLY SUPPORTED**